auide.

THANK YOU FOR BUYING AN INDESIT PRODUCT.

In order to receive a more complete assistance, please register your appliance on: www.indesit.com/register


your appliance on: www.indesit.com/register

Before using the appliance carefully read Safety Instructions

PLEASE SCAN THE QR CODE ON YOUR APPLIANCE IN ORDER TO HAVE MORE DETAILED INFORMATION



CONTROL PANEL



- 1. ON-OFF/Reset button with indicator light
- 2. Push & Go button with indicator light
- 3. Salt refill indicator light
- 4. Program selection knob
- 5. Delay indicator lights
- 6. Delay button with indicator light
- 7. START/Pause button with indicator light / Drain out

FIRST TIME USE

FILLING THE SALT RESERVOIR

The use of salt prevents the formation of LIMESCALE on the dishes and on the machine's functional components.

- It is mandatory that THE SALT RESERVOIR NEVER BE EMPTY.
- It is important to set the water hardness.

The salt reservoir is located in the lower part of the dishwasher (see PRODUCT DESCRIPTION) and must be filled when the **SALT REFILL** indicator light (s) in the control panel is lit.




 Remove the lower rack and unscrew the reservoir cap (anticlockwise).

- 2. Only the first time you do this: fill the salt reservoir with water.
- 3. Position the funnel (see figure) and fill the salt reservoir right up to its edge (approximately 1 kg); it is not unusual for a little water to leak out.
- 4. Remove the funnel and wipe any salt residue away from the opening. Make sure the cap is screwed on tightly, so that no detergent can get into the container during the wash program (this could damage the water softener beyond repair).

Whenever you need to add salt, it is mandatory to complete the procedure before the beginning of the washing cycle to avoid corrosion.

FILLING THE RINSE AID DISPENSER



Rinse aid makes dish DRYING easier. The rinse aid dispenser **A** should be filled when when the dark optical indicator on the dispenser door **C** becomes transparent.

NEVER pour the rinse aid directly into the appliance tub.

FILLING THE DETERGENT DISPENSER

To open the detergent dispenser use the opening device **D**. Introduce the detergent into the dry dispenser **E** only. Place the amount of detergent for pre-washing directly inside the tub.

Usage of detergent not designed for dishwashers may cause malfunction or damage to the appliance.

WATER SOFTENING SYSTEM

Water softener automatically reduces water hardness, consequently preventing scale buildup on heater, contributing also to better cleaning efficiency. This system regenerates itself with salt, therefore it is required to refill salt container when empty.

Frequency of regeneration depends on water hardness level setting - regeneration takes place once per 6 Eco cycles with water hardness level set to 3. Regeneration process starts in final rinse and finishes in drying phase, before cycle ends.

- Single regeneration consumes: ~3.5L of water;
- Takes up to 5 additional minutes for the cycle;
- Consumes below 0.005kWh of energy.

PROGRAMS TABLE

Program		Programs description	Drying phase	Avaiable options *)	Duration of wash program (h:min)**)	Water consumption (litres/cycle)	Energy consumption (kWh/cycle)
1.	FCO	Eco 50°- Eco program is suitable to clean normally soiled tableware, that for this use, it is the most efficient program in terms of its combined energy and water consumption, and that it is used to assess compliance with the EU Ecodesign legislation.	✓	Ŷĥ	3:35	9.5	0.95
2.	\bigcirc	Intensive 65° - Program recommended for heavily soiled crockery, especially suitable for pans and saucepans (not to be used for delicate items).	√	(℃h	2:40	18.0	1.60
3.		Mixed 55° - Mixed soil. For normally soiled dishes with dried food residues.	٧	⊘ h	2:15	16.0	1.40
4.	€ 7% 28′	Fast&Clean 28' 50° - Program to be used for half load of lightly-soiled dishes with no dried food residues. Does not have drying phase.	-	⊘ h	0:28	9.0	0.50
5.	\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\	Pre-Wash - Use to refresh crockery planned to be washed later. No detergent to be used with this program.	-	(℃h	0:12	4.7	0.01
6.	PUSH& G⊙	Push&GO 50° - Everyday wash and dry cycle that ensures great cleaning performance in a short time without the need to pre-treat dishes.	✓	-	1:30	11.5	1.30

ECO program data is measured under laboratory conditions according to European Standard EN 60436:2020.

Note for Test Laboratories:

For information on comparative EN testing conditions, please send an email to the following address: dw_test_support@whirlpool.com Pre-treatment of the dishes is not needed before any of the programs.

*) Not all options can be used simultaneously.

^{**)} Values given for programs other than the program Eco are indicative only. The actual time may vary depending on many factors such as temperature and pressure of the incoming water, room temperature, amount of detergent, quantity and type of load, load balancing, additional selected options and sensor calibration. The sensor calibration can increase program duration up to 20 min.



OPTIONS AND FUNCTIONS

Please scan the **QR code** on your appliance in order to have more detailed information

OPTIONS can be selected directly by pressing the corresponding button (see CONTROL PANEL). If an option is not compatible with the selected program (see PROGRAMS TABLE), the corresponding LED flashes rapidly 3 times. The option will not be enabled.

FOLDABLE

FLAPS WITH AD-

JUSTABLE POSITION

PUSH&GO - Push&Go button is an easily distinguishable button that allows you direct access to the Push&Go program, a wash and dry cycle that ensures great cleaning performance in a short time. You don't have to worry which program to choose, Push&Go cycle will do the work for you. To select Push&Go program, switch on appliance, press only Push&GO button for 3 seconds.


DELAY - It is possible to delay the start time of the program by 2, 4 or 8 hours.

The DELAY function cannot be set once a program has been started.

DRAIN OUT - To stop and cancel the active cycle, the Drain Out function can be used. A long press of START/PAUSE button, will activate the DRAIN OUT function. The active program will be stopped and the water in the dishwasher will be drained out.

LOADING THE RACKS


UPPER RACK



(loading example for the upper rack)

Load delicate and light dishes: glasses, cups, saucers, low salad bowls.

LOWER RACK




(loading example for the lower rack)

For pots, lids, plates, salad bowls, cutlery etc.. Large plates and lids should ideally be placed at the sides to avoid interferences with the spray arm.

CUTLERY BASKET



CAPACITY: 14 standard place-settings




Knives and other utensils with sharp edges must be placed in the cutlery basket with the points facing downwards or they must be positioned horizontally in the tip-up compartments on the upper rack.


CLEANING AND MAINTENANCE

More information in the **Daily Reference Guide** on website.

CLEANING THE FILTER ASSEMBLY








In case you find foreign objects (such as broken glass, porcelain, bones, fruit seeds etc.) **please remove them carefully**.

NEVER REMOVE the wash-cycle pump protection (black detail) (Fig 4).

CLEANING THE SPRAY ARMS



To remove the upper spray arm, turn the plastic locking ring in a clockwise direction.



The lower spray arm may be removed by pulling it upwards.

Policies, standard documentation, ordering of spare parts and additional product information can be found by:

- · Using QR code on your product.
- Visiting our website docs.indesit.eu and parts-selfservice.whirlpool.com
- Alternatively, **contact our After-sales Service** (See phone number in the warranty booklet). When contacting our After-sales Service, please state the codes provided on your product's identification plate.

The model information can be retrieved using the QR-Code reported in the energy label. The label also includes the model identifier that can be used to consult the portal of the registry at https://eprel.ec.europa.eu.



