



Your touch brings it to life

The AEG Pure 3 hob combines a sleek, seamless design with responsive functions. Ebony glass blends seamlessly with the worktop. Its cooking zones and controls are invisible until your fingertips bring them to life. Transform the kitchen and turn cooking into a true pleasure.

The AEG Pure 3 hob combines a sleek, seamless design with responsive functions. Ebony glass blends seamlessly with the worktop. Its cooking zones and controls are invisible until your fingertips bring them to life. Transform the kitchen and turn cooking into a true pleasure.

Product Benefits & Features

Your touch brings it to life

Imagine a glossy sheet of pure ebony glass that blends seamlessly with your worktop. Its cooking zones and touch controls are invisible until your fingertips bring them to life. The AEG MaxiSense Pure hob combines a sleek design with responsive functions, transforming your kitchen and turning



- Acoustic timer signal
- Easy to reach front controls
- Auto safety switch off
- Child safety control lock
- 99 minute timer with acoustic signal
- Simple touch sensor controls
- Full induction hob
- Right front zone: Induction - 2300/3200W/210mm
- Control lock
- Middle rear zone: No -
- Left front zone: Induction - 2300/3200W/210mm
- Middle front zone: No -
- Right rear zone: Induction - 2300/3200W/210mm
- Residual heat indicators
- Powerful booster
- Front left: 1 large induction zone with booster
- Wipe clean ceramic hob surface

The adaptable surface for every pan

The MaxiSense® self-sizing cooking zones detect the sizes and shapes of each pan. However large or small. It sends immediate heat to fit their bases, without compromising on performance. Experience the ultimate in kitchen adaptability. For complete culinary control.



Hob2Hood - Cook without distractions

This hob has Hob2Hood, a useful feature that automatically controls your cooker hood and lights. It means you don't get distracted by trying to regulate the fan when you're at crucial cooking moments: you can simply concentrate on getting your dish right. But if you'd rather adjust the fan speed



Zone in with intuitive controls

By turning the hob on and placing a pan down, the LED slider control automatically lights up. Intuitively showing which zone to use. Avoid placing a pot on an inactive zone, and experience the full power of cooking with AEG.

Each cooking zone. Individually timed

Once a cooking zone is in use, its timer can be accessed quickly and conveniently via the touchscreen display. No toggling through menus or other zones. And because each dish can be precisely timed individually, absolute control over the cooking process is assured.

Product Specification

PNC	949 597 526
EAN number	7332543669158
Width (mm)	780
Depth (mm)	520
Voltage	220-240/400V2N
Net Weight	12.54
Colour	Black

